

INSTRUCTION

26-2017

RZB
LIGHTING

Toledo Flat

901496.002.76



IP 40 IK06






220 - 240 V / 0/50/60 Hz



4 x 1,5 mm²



1,50 mm²



	L1	L2	L3	D1
901495.002.X	60	30	103,9	Ø120
901496.002.X.X	81	40,5	140,3	Ø162
901497.002.X.X	113,5	56,8	196,6	Ø227
901498.002.X.X	137,5	68,8	238,2	Ø275



901496.002.76

D 192, H 58

LED

9 W

1,26 kg



EEK_{LED}

EEK

CRI

CCT


740 lm

A

A

80

3000K



45

80

0

0

17 A



Die Leuchte darf nur mit ihren vollständigen Schutzabdeckungen betrieben werden.
The luminaire must be used with its complete protective covers only.

EN 12464



EN 12464




EN 12464
Wartungsplan/
Maintenance
schedule




RZB
Rudolf Zimmermann,
Bamberg GmbH
Rheinstraße 16
D-96052 Bamberg
Deutschland
Telefon +49 951/79 09-0
Telefax +49 951/79 09-198
www.rzb.de
info@rzb-leuchten.de


1



2




3




4


DALI




5




6



7





	L1	L2	L3	D1
901495.002.X	60	30	103,9	Ø120
901496.002.X.X	81	40,5	140,3	Ø162
901497.002.X.X	113,5	56,8	196,6	Ø227
901498.002.X.X	137,5	68,8	238,2	Ø275

