



DIN 4844





Vor Wartung oder Reparatur freischalten/
power off before maintenance or repair

INSTRUCTION

Industrial Hall

CE



982114.004

D327, H150

313 g



EN 12464



