

INSTRUCTION

26-2017



Toledo Flat

901552.002






IP 40 IK06



200 - 240 V / 50/60 Hz



2 x 1,5 mm²



	L1	L2
901551.002.X	40	-
901552.002.X.X	70	-
901553.002.X.X	93	93
901554.002.X.X	120	120



901552.002

L 172, B 172, H 58

LED

8 W

1,03 kg



EEK_{LED}

EEK

CRI

CCT

730 lm

A+

A+

80

3000K



36



57



36



57



instruction
Wartungsplan/
maintenance
schedule



DIN EN 61340-5-1



Die Leuchte darf nur mit ihren vollständigen Schutzabdeckungen betrieben werden.
The luminaire must be used with its complete protective covers only.

EN 12464



EN 12464




EN 12464

Wartungsplan/
Maintenance
schedule




RZB
Rudolf Zimmermann,
Bamberg GmbH
Rheinstraße 16
D-96052 Bamberg
Deutschland
Telefon +49 951/79 09-0
Telefax +49 951/79 09-198
www.rzb.de
info@rzb-leuchten.de


1



2




3




2x
(4x)


4






L N
(brown) (blue)



5





	L1	L2
901551.002.X	40	-
901552.002.X.X	70	-
901553.002.X.X	93	93
901554.002.X.X	120	120

