living

beurer



FW 20 Cosy Fußwärmer

- Flauschig weiche Oberfläche aus Micro-Flauschfaser
- BSS (Beurer Sicherheits System)
- Elektronische Temperaturregelung
- 3 beleuchtete Temperaturstufen
- Abschaltautomatik nach ca. 90 Minuten
- Schnellheizung
- Herausnehmbares Teddyfutter
- Teddyfutter handwaschbar
- Öko-Tex 100

Die bei diesem Gerät eingesetzten Textilien erfüllen die hohen humanökologischen Anforderungen des Öko-Tex Standards 100, wie durch das Forschungsinstitut Hohenstein nachgewiesen.

- 100 Watt
- Ca. 32 x 26 x 26 cm
- 3 Jahre Garantie

- Versandeinheit: 6
- EAN-Nr.: 4211125 53104 1
- Art-Nr.: 531.04

FW 20 Cosy-Foot warmer

- Cosy soft foot warmer made of cosy micro-fibre
- BSS (Beurer Safety System)
- Electronic temperature control
- 3 illuminated temperature settings
- Automatic switch off after approx. 90 minutes
- Rapid heat up
- Removable teddy fleece
- Teddy fleece hand washable
- Oeko-Tex 100

The textiles used for this device meet the stringent human ecological requirements of Oeko-Tex Standard 100, as verified by Hohenstein Research Institute.

- 100 watt
- Approx. 32 x 26 x 26 cm
- 3 year guarantee

- Sales unit: 6
- EAN no.: 4 211125 53104 1
- Item number: 531.04

0511 Irrtum und Änderungen vorbehalten